



Renegade

Vibrating • Rechargeable
HEAD UNIT

- Vibration:** 10 modes
Battery: USB Rechargeable
Lithium Polymer
Charge Time: Approximately
120 minutes
Play Time: Approximately
60 minutes
Material: ABS+Silicone
Waterproof: IPX 7



**CHARGE
PORT**



HOW TO PLAY

Press and hold **POWER BUTTON** for 3 seconds to turn on your Renegade Head Unit. Press power button to explore 10 different vibration modes. Press and hold the power button for 3 seconds again to turn it off.

HOW TO CARE

- *Turn off your Renegade Head Unit when not in use.
- *Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with soft, cotton towel and allow to air dry completely.

For warranty information,
latest products and news, visit us at: nsnovelties.com

nsnovelties

Document Name	Renegade Head Unit User Guide
Last Modified	1-17-2019
Size	21 cm w x 10.5 cm h
Format	Accordion Fold

Cut ———— Fold - - - - -

Copyright © 2018 NS Novelties. All rights reserved. The shape and appearance of this packaging and enclosed product is a trademark and trade dress of NS Novelties.

Renegade


Vibrating • Rechargeable HEAD UNIT

HOW TO PLAY

Press and hold **POWER BUTTON** for 3 seconds to turn on or off your Renegade Head Unit. Press power button quickly to explore 10 different vibration modes. For maximum pleasure, use lubricant with your Head Unit.

HOW TO CARE

Turn off your Renegade Head Unit when not in use.
Wash after each use with liquid anti-bacterial soap and water.
Pat dry with soft, cotton towel and allow to air dry completely.



- Vibration:** 10 modes
Battery: USB Rechargeable
Lithium Polymer
Charge Time: Approximately
120 minutes
Play Time: Approximately
60 minutes
Material: ABS+Silicone
Waterproof: IPX 7

For warranty information, latest
products and news, visit us at:

nsnovelties.com

nsnovelties

Document Name	Renegade Head Unit User Guide
Last Modified	1-17-2019
Size	21 cm w x 10.5 cm h
Format	Accordion Fold

Cut ———— Fold - - - - -

Copyright © 2018 NS Novelties. All rights reserved. The shape and appearance of this packaging and enclosed product is a trademark and trade dress of NS Novelties.

Renegade


Vibrating • Rechargeable HEAD UNIT

HOW TO PLAY


Press and hold **POWER BUTTON** for 3 seconds to turn on or off your Renegade Head Unit. Press power button quickly to explore 10 different vibration modes. For maximum pleasure, use lubricant with your Head Unit.

HOW TO CARE

Turn off your Renegade Head Unit when not in use. Wash after each use with liquid anti-bacterial soap and water. Pat dry with soft, cotton towel and allow to air dry completely.



- Vibration:** 10 modes
- Battery:** USB Rechargeable
Lithium Polymer
- Charge Time:** Approximately
120 minutes
- Play Time:** Approximately
60 minutes
- Material:** ABS+Silicone
- Waterproof:** IPX 7



For warranty information, latest products and news, visit us at:

nsnovelties.com

nsnovelties

Document Name	Renegade Head Unit User Guide
Last Modified	1-17-2019
Size	21 cm w x 10.5 cm h
Format	Accordion Fold

Cut ———— Fold - - - - -

Copyright © 2018 NS Novelties. All rights reserved. The shape and appearance of this packaging and enclosed product is a trademark and trade dress of NS Novelties.