

# SEDUCTION

## ROXY

For warranty information, latest products, and news visit us at:  
[nsnovelties.com](http://nsnovelties.com)

### CARE

- \* Turn off device when not in use.
- \* Do not operate the device while charging.
- \* Please follow the charge times indicated in the device specifications.
- \* Wash after each use with liquid anti-bacterial soap and water.
- \* Pat dry with a cotton towel and allow to air dry completely.


#### Product

- Dimensions:** 3.54x0.67x0.67(in)  
**IPX Rating:** IPX7 Waterproof 30 min. immersion 3 ft.  
**Battery:** Rechargeable  
**Charge Time:** Do not exceed 60 minutes  
**Run Time:** 45 minutes  
**Modes:** 10



### PLAY

- \* Press & hold power button for 2 seconds to power on/off.
- \* Quick press power button to cycle through speeds/functions.



### CHARGE

- \* The light will blink while the device is charging.
- \* The light will become solid once the device is fully charged.

