

desire

AMORE

For warranty information, latest products, and news visit us at:  
[nsnovelties.com](http://nsnovelties.com)

#### CARE

- \* Turn off device when not in use.
- \* Do not operate the device while charging.
- \* Please follow the charge times indicated in the device specifications.
- \* Wash after each use with liquid anti-bacterial soap and water.
- \* Pat dry with a cotton towel and allow to air dry completely.

#### Product

**Dimensions:** 8.58 x 114 x 114 (in)

**IPX Rating:** IPX6 High pressure water resistant

**Battery:** Rechargeable

**Charge Time:** Do not exceed 120 minutes

**Run Time:** 60 minutes


**Modes:** 10



#### PLAY

- \* Press & hold power button for 2 seconds until indicator light blinks to power on and enter standby mode.
- \* Quick press button on either side to cycle through speeds/functions.
- \* Press & hold power button for 2 seconds to power off.

BUTTON →  
POWER →  
BUTTON →



#### CHARGE

- \* The light will blink while the device is charging.
- \* The light will become solid once the device is fully charged.

