

INYA

CAPRISE RECHARGEABLE RABBIT

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.


Product Dimensions: 6.97 x 1.77 x 3.27 (in)
IPX Rating: IPX6 High pressure water resistant
Battery: Rechargeable
Charge Time: Do not exceed 120 minutes
Run Time: 45 minutes
Modes: 11



PLAY

- * Press & hold any button on device for 2 seconds until indicator light turns on to power on and enter standby mode.
- * Quick press thrust button to activate thrust setting.
- * Quick press vibration button to activate and cycle through vibration and clitoral stimulation speeds/functions.
- * Press & hold any button on device for 2 seconds to end functions and power off.

THRUST
VIBRATION



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

