


Renegade

THE HANDYMAN CR AND PROSTATE MASSAGER WITH REMOTE

For warranty information, latest products, and news visit us at:
nsnovelties.com

PLAY


- * Press & hold power button for two seconds until indicator light turns on to power on and enter standby mode.
- * Quick press the power button to cycle through thruster speeds/functions.
- * Quick press the vibration button to cycle through vibration speeds/functions.
- * Press & hold power button for two seconds to power off.



SET UP


PLAYING WITH REMOTE

- * To use the remote, put the device in standby mode.
- * Quick press the top button to activate and cycle through thruster speeds/functions.
- * Quick press the bottom button to activate and cycle through vibration speeds/functions.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.



CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 5.71 x 2.13 x 4.06 (in),
Remote: 3.15 x 1.54 x 1.1
IPX Rating: IPX7 Waterproof 30 min. immersion 3 ft.,
Remote: IPX4 Splashproof
Battery: Rechargeable, Remote: AAA
Charge Time: Do not exceed 120 minutes
Run Time: 50 minutes
Modes: 14

