


FRONT

5

CHARGE

* The light will blink while the device is charging.
* The light will become solid once the device is fully charged.







6

CARE

* Turn off device when not in use.
* Do not operate the device while charging.
* Please follow the charge times indicated in the device specifications.
* Wash after each use with liquid anti-bacterial soap and water.
* Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 4.29 x 2.28 x 1.34 (in)
IPX Rating: IPX7 Waterproof 30 min. immersion 3 ft.
Battery: Rechargeable
Charge Time: Do not exceed 120 minutes
Run Time: 60 minutes
Modes: 15



1

techno

PRISM
APP-CONTROLLED
VIBRATING AND
GYRATING PLUG


For warranty information,
latest products, and news visit us at:
nsnovelties.com

BACK

2

SET UP

* Scan the QR code below to download the App **Love Spouse** or search "Love Spouse" on Google Play or App Store to download.




3

SET UP

* After **Love Spouse** is downloaded, register and log into the App. (Bluetooth must be on. There is no personal information needed to register.)
* Press "+" in the App.
* Scan QR code below to pair the vibe with your mobile device.
—Or—
* Press "Enter device code".
* Type "**8039**" and press "yes" to pair the vibe with your mobile device.

8039



4

PLAY

* Press & hold the power button for 2 seconds to power on and enter standby mode.
* Quick press the power button to cycle through vibration speeds/functions.
* Quick press the gyrate button to activate and cycle though gyration speeds/functions.
* Press & hold the power button for 2 seconds to power off.

