

Product Specifications:

Category: Vibrator Material: Silicone+ABS Size: H: 5.13" D: 1.2" W: 1.2" Battery: Li-ion Battery Voltage: 500mAh Number of Vibrations: 1PCS motor with 10 different vibration modes User time: 50mins in hightest level,60mins in lowest level. Sound Level: <50Db

CHARGING INSTRUCTIONS

CHARGING INSTRUCTIONS
This vibrator arrives with a minimal partial charge, between 30% – 50% of its full capacity. It is not necessary to fully charge before use, but it will not damage the battery to charge it before expending the initial existing battery charge.
Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. Initial charge will take about 2 hours, and subsequent charges will also take about 2 hours to complete.

The indicator light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.
Charge lasts for about 1 hour of play time on the lowest level of vibration, and about 50 minutes on the highest level.

Toy vibration stops completely when charge begins

Toy vibration stops completely when charge begins to deplete.

This toy operates at a sound level of 50db with a 3.7V, 500mAh battery

INSTRUCTIONS FOR USE

This toy has a convenient one-button control at its base.

To turn toy on, press the button for at least 3 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the button a single time for each USB RECHARGEABLE new speed or function for a total of 10.

To turn toy off, press power button for at least 3 seconds.





