

<http://www.genderx.com/>

**GENDER X**



**Product Specifications:**

Material: Silicone, ABS  
Battery: LiCoMnNiO2  
Voltage: 3.7-4.2 V  
Number of Vibrations: 10  
User time: 60-80 MINS  
Sound Level: ≤60dB/10cm

**CHARGING INSTRUCTIONS**

This vibrator arrives with a partial charge, so it is recommended to charge for about 30 minutes before use. Connect the USB end of the charging cable into the port of your power source and the other end onto the magnetic charging pins located below the beaded shaft on the toy.



Initial charge will take about 30 minutes, and subsequent charges will take about 2 hours to complete. The indicator light will flash while device is charging and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time. Charge lasts for about 80 minutes of play time on the lowest level of vibration, and about 60 minutes on the highest level. This toy operates at a sound level of less than 60db with a rechargeable lithium battery at 3.7V - 4.2V.

**INSTRUCTIONS FOR USE**

This toy has a convenient 2-button control at its center line, underneath the rabbit stimulator. Press the top button for 3 seconds to engage three motors at once - the center shaft, beaded shaft and rabbit stimulator. The LED light will turn on, and all 3 motors will begin at their lowest vibrational frequency. Press the button again more quickly to cycle through 10 speeds and functions. To turn off, press again for 3 seconds. The LED light will turn off and vibration will cease for all 3 motors. Press the bottom button for 3 seconds to engage the pointed tip shaft at the bottom of the toy. The LED light will turn on, and the pointed tip motor will begin at its lowest vibrational frequency. Press the button again more quickly to cycle through 10 speeds and functions. To turn off, press again for 3 seconds. The LED light will turn off and vibration will cease.