



VIBRATOR CARE INSTRUCTIONS

1. Take care when using the vibrator for the first time. Vibration can be intense.
2. Clean your vibrator after every use.
3. Take care when cleaning your vibrator. Remember it is an electrical item.
4. Keep your vibrator clean and dry. Store in a non-damp environment.
5. Always store your vibrator separately. Different materials have different chemical configurations and may react with each other.
6. Always allow your vibrator to cool down before storing in a safe place. Vibrators are electrical and motors grow warm with use.
7. Excessive usage of the vibrator will wear out the motor and may cause the motor to overheat. If you feel your vibrator is getting unduly hot, switch off and allow it to cool down, before continuing use.
8. Take care when using oils and lubricants so that they do not enter the battery compartment as they can react with the batteries.



CHARGING INSTRUCTIONS

This toy arrives with a high partial charge of 80%. It is recommended to use up this energy completely before charging the first time.

To charge, connect the USB plug into the USB port of your computer or other output and the DC charger into the port at the base of the handle of the toy.

Initial and subsequent charges will take about 2 hours to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time. Charge lasts for about 50 minutes of play time.

This toy operates at a sound level of less than 48db with a rechargeable lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at the front of its handle.

To turn toy on, press the button for at least 1.5 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency in both motors. Once the toy is on, press the button again, a single time for each new speed or function for a total of 10.

To turn toy off, press Power Button for at least 1.5 seconds.

USB RECHARGEABLE