

Product Specifications:

Material: ABS & TPE
Battery: Lithium battery,
902040 700mAh
Voltage: 3.7V
Number of Vibrations: 3
User time: 120 - 140 Minutes
Sound Level: ≤65DB

CHARGING INSTRUCTIONS

This vibrator arrives with high partial charge of 70 – 80% but it is recommended to charge fully before first use. Initial charge will take about 90 minutes, and subsequent charges will take about 2 hours to complete.

To charge, connect the USB plug into a power source and the other end of the DC charger into the port located at the very bottom of the toy's handle.



The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 140 minutes of play time on the lowest level of function and 120 minutes on the highest level. This toy operates at a sound level of 65db with a 700mAh lithium battery at a voltage of 3.7V.

INSTRUCTIONS FOR USE

This toy has a 1-button control at the side of its handle. To turn toy on, press the button for at least 3 seconds. The INSERT LED light will turn on and toy will begin CHARGER stroking at its lowest frequency. Press the button again more quickly to cycle through 3 speeds in total. To turn toy off, press button for at least 3 seconds.

USB RECHARGEABLE