

FemmeFunn[®]

Power • Innovation • Fun



BOOSTER BULLET

USER MANUAL

BOOSTER BULLET

Good things really do come in small packages. Booster Bullet rockets you to climax with 20 arousing vibration modes and ultra hygienic, soft-to-the-touch silicone. Waterproof and travel-friendly, it's ready for every intimate adventure.

Features:



20 VIBRATION
MODES



PREMIUM
SILICONE



BOOST
MODE



MEMORY
FUNCTION



MAGNETIC
CHARGING



MAGNETIC
CHARGING CASE



100%
WATERPROOF

SPECIFICATIONS / DIMENSIONS

Colors:



Length:

4.3 inches

Width:

1.1 inches

Material:

Premium Silicone

Battery:

Li-ion

Charging Voltage:

5V/1200mA

Run Time:

Approx. 70 Minutes
at Highest Setting*




Charge Time:

Approx. 2 Hours*



*Charging and use times are estimates only. Battery life varies over time, and all batteries experience a decline in useful life over time.

HOW TO USE

- 1) To turn on or off: Press and hold  button on toy for 3 seconds.
- 2) Press the  once to cycle through the different vibration modes.
- 3) To use Boost mode, press  button once. To return to the previous vibration mode, press Boost button once or wait for 10 seconds.
- 4) If using lubricant, use a water-based lubricant ONLY. **DO NOT USE silicone-based lubricants, massage oils, hand creams, lotions, or similar non-water-based lubricants with this product.**

CHARGING

- 1) Completely dry toy before charging.
- 2) If charging toy directly, carefully connect magnetic charging cable to toy. NOTE: Toy must be placed on a flat surface for charger to connect properly. Connect USB to power source. Flashing

light on toy means toy is charging. Solid light on toy means toy is fully charged.

- 3) If charging toy through the charging case, make sure the charging points on the toy are aligned with the contact pins in the case. Carefully connect magnetic charging cable to the external charging points on the case. The red light will turn on and stay solid. While charging, only the light on the toy will blink; the light on the case does not blink.
- 4) Only use the original charger provided with the toy when charging.
- 5) Disconnect charger once toy is fully charged. Do not leave the charger connected if toy is fully charged.
KEEPING THE CHARGER CONNECTED WHEN TOY IS FULLY CHARGED MAY CREATE A FIRE HAZARD. Keep charger away from metal items.
- 6) Do not use toy when it is charging.

CLEANING AND STORAGE

- 1) Completely dry toy before charging.
- 2) Always clean toy before and after each use.
- 3) ONLY use a toy cleaner specifically formulated to clean and sanitize adult toy products. After cleaning, rinse with warm water before use.
- 4) Allow toy to air dry. Do not use any other means to dry the product.
- 5) This product is NOT dishwasher safe. Do NOT place in a dishwasher, washing machine, dryer or similar appliance.
- 6) Store toy in a cool, dry place.
- 7) Use of any other cleaning products or methods may damage the product and will invalidate your limited warranty.

SAFETY

- 1) This product is designed for your pleasure, however, we can only recommend external use. Internal use is always at your own risk.
- 2) For health reasons, do not share this toy with others. Such use is at your own risk.
- 3) If using lubricant, use a water-based lubricant ONLY. DO NOT USE silicone-based lubricants, massage oils, hand creams, lotions, or similar non-water-based lubricants with this product.
- 4) If you experience any discomfort, or notice any unusual medical symptoms after using this product, discontinue use immediately, and contact your doctor or other health professional.
- 5) If any part of this product is damaged, immediately discontinue use, and contact us.
- 6) KEEP OUT OF REACH OF CHILDREN AND PETS.

- 7) DO NOT attempt to take apart or disassemble the toy. Any such attempt voids any warranty.

Our products and materials are fully tested pursuant to California's Proposition 65, and meet or exceed the safety thresholds set by California, and are therefore exempt from Proposition 65 warnings.

DISCLAIMER OF WARRANTIES

Company's Products must be stored, handled, used and maintained in accordance with instructions provided by Company, and this Limited Warranty is conditioned upon compliance with all such instructions. If you do not have a copy of Company's User Manual for Product, it is available from us by contacting us at info@femmefunn.com.

This Limited Warranty does not cover defects caused by:

- 1) Non-compliance with Company's User Manual and other instructions. Such failures include, but are not limited to, exposure to physical abuse, including, but not limited to use in any manner not described in the User Manual, chemical abuse (e.g. use of harsh cleansers and solvents), thermal abuse or shock (e.g. excessive heat or cold);
- 2) Improper storage, installation, handling, use and/or fabrication of the Product;
- 3) Damage not resulting from manufacturing defects that occur while the Product is in the customer's possession;

- 4) Unreasonable or unintended use of Product;
- 5) Products used with known or visible manufacturing defects at the time of purchase;
- 6) Minor conditions such as stains, scratches, color variations;
- 7) Mere dissatisfaction with Product or its appearance. Any information or suggestion by Company with respect to the Products concerning applications, specifications or compliance with codes and standards is provided solely for your convenient reference and are made without any representation as to accuracy or suitability.

THE WARRANTIES SET FORTH HEREIN ARE THE ONLY WARRANTIES MADE BY COMPANY IN CONNECTION WITH THE PURCHASE AND USE OF COMPANY'S PRODUCTS. COMPANY CAN NOT AND DOES NOT MAKE ANY IMPLIED OR EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, AND DISCLAIMS ALL OTHER WARRANTIES, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. PRODUCTS SOLD BY COMPANY ARE SOLD ONLY TO THE SPECIFICATIONS SPECIFICALLY SET FORTH BY COMPANY IN WRITING. OTHER THAN THE LIMITED WARRANTY SET FORTH HEREIN, COMPANY MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED.

COMPANY'S SOLE OBLIGATION UNDER THIS WARRANTY SHALL BE REPLACEMENT OF NON-CONFORMING PRODUCTS, OR AT THE OPTION OF COMPANY, A REPLACEMENT WITH THE SAME OR SIMILAR PRODUCT. BUYER ASSUMES ALL RISK WHATSOEVER AS TO THE RESULT OF THE USE OF THE PRODUCTS PURCHASED, WHETHER USED SINGULARLY OR IN COMBINATION WITH ANY OTHER PRODUCTS OR SUBSTANCES.

Limitation of Liability

No claim by the buyer/owner of any kind, including claims for indemnification, shall be greater in amount than the purchase price of the Products in respect to which damages are claimed. IN NO EVENT SHALL COMPANY BE LIABLE TO

BUYER/OWNER IN TORT, CONTRACT OR OTHERWISE, FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, RELIANCE, STATUTORY, SPECIAL, PUNITIVE OR EXEMPLARY DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, LOSS OF USE, LOSS OF TIME, LOSS OF REVENUES, INCONVENIENCE, LOSS BUSINESS OPPORTUNITIES, DAMAGE TO GOOD WILL OR REPUTATION, OR LOSS OF DATA, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR SUCH DAMAGES COULD HAVE BEEN REASONABLY FORESEEN, IN CONNECTION WITH, ARISING OUT OF, OR AS A RESULT OF, THE SALE, DELIVERY, SERVICING, USE OR LOSS OF USE OF THE PRODUCTS SOLD HEREUNDER, OR FOR ANY LIABILITY OF BUYER TO ANY THIRD PARTY WITH RESPECT THERETO.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

CONTACT INFORMATION

Any question concerning this warranty should be addressed to Vvole LLC at info@femmefunn.com

FemmeFunn[®]
Power • Innovation • Fun

www.femmefunn.com

© FemmeFunn. All Rights Reserved.