


ENLARGE

VIKING

For warranty information, latest products, and news visit us at:
nsnovelties.com

PLAY

1. Press & hold power button  for 3 seconds until screen displays to power on and enter standby mode.
2. Press power button  once to activate suction mode.
3. Press power button  once to pause suction at desired pressure.
4. Press & hold release button  to completely release suction.




SET UP

5. To setup "smart" mode, press power button  to reach desired pressure. Once desired pressure has been reached, press power button again to hold suction at desired pressure. Press & hold smart button  for 3 seconds to activate and an  icon will appear in the bottom of the screen to indicate the pressure has been set. Press smart button to activate smart mode and an  icon will appear in the bottom left corner of the display once activated. Pump will start suction to the desired pressure, then release the suction automatically. This pattern will repeat for 20 minutes. To increase the holding time, press smart button  during smart mode. Original holding time is 0, each press is equal to 1 minute. The hold time displays on the top left of the display. Maximum holding time is 10 minutes.
6. Press & hold power button  for 3 seconds to power the device off.

CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.



CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 12.64 x 2.8 x 2.8 (in)
IPX Rating: IPX6
Battery: Lithium
Charge Time: Do not exceed 120 minutes
Run Time: 120 minutes
Modes: 2

